

ME 02.74/740: Bio-inspired Robotics  
Documentation: Copy to mbed  
Rev. 01, Sept. 2015

---

Mac OS 10.10 (prior to 10.10.3) has a bug which prevents copying files to any mbed device. This utility provides a workaround for the bug. If you are up to date with the most recent OS X security updates, you don't need this fix.

1. To install, simply unzip the provided file, and double click "Copy to mbed.workflow" to install.




Figure 1: Double click "Copy to mbed.workflow" and select "Install" to install the fix.

2. Following this simple installation, you can copy a file to the FRDM board by simply right clicking on the compiled bin file, and selecting "Copy to mbed" from the dropdown. You'll be requested to input an administrator password to execute the copy.




Figure 2: Upon install a right-click context menu should provide "Copy to mbed" as an option

3. If you even want to install the service, you can delete it from your home folder in *Library* → *Services*.